

QuickLynk™

Lynkwell's automated onboarding solution



- ✓ No phone calls.
- ✓ No log-ins.
- ✓ No delays.
- ✓ No confusion.
- ✓ Just **fast & easy** EV charging deployment.



Configuration goes from hours to a few minutes

Installers

Complete more projects in a day

- Save hours field-configuring stations. XLYnk™ configures itself.
- No more waiting hours or days for remote support. Power, connect, move on.

Site Hosts

Full control over your charger & location activation


- Activate chargers on your own, when you're ready.
- Configure your new EV charging location from anywhere.

Supported by Lynkwell's 24/7 US-based support team

Installer

1


Register your Project with Lynkwell



1. Have QR codes from XLink™ boxes or write down serial numbers
2. Scan QR code inside XLink™ box to access **Project Registration Form**
3. Fill out your company info
4. Fill out basic Site Host info
5. Add stations and key contacts

2


Install & Power XLink™



1. Mount XLink™ chargers and power all at the same time
2. Gateway automatically connects
3. Non-Gateways get connected based on serial numbers provided in the **Project Registration Form**

3


Confirm Stations Are Connected



1. Check XLink™ screen to see status of automated provisioning
2. Installer uses emailed link to access **Station Status Page**
3. When all stations connect the site host receives an automated activation email

Support for Every Step


No site is the same, no project is the same. We get it. Having deployed thousands of EV chargers across a myriad of use cases, the Lynkwell team has seen and solutioned for it all.



 **Site Host**

4

Site Host Completes Activation




1. Site host uses **Activation Form**
2. Provides company information
3. Enters information about their location, pricing, etc.

 **Lynkwell**

5

Location Visible On ViaLynk™ app



1. Lynkwell support team confirms everything is ready
2. Deploys stations to ViaLynk™ network

QuickLynk™ is designed specifically to make the onboarding process as simple, fast, and “low-touch” as possible. However, if you require additional support at any point during the project, know that

Lynkwell's team of hardware, software, and service experts are always available. **We provide 24/7 US-based support to ensure a great experience for our partners, site hosts, and drivers.**

Fast, reliable, repeatable deployments, every time

Introducing QuickLynk™, Lynkwell's fully streamlined installer and site host experience



Save Hours, Register your Project

Installers complete a quick online form before or after arriving on-site—saving hours on the project. No login, credit card entry, portal navigation, system setup, gateway configurations, or individual charger programming required.



Simply Install & Power, QuickLynk™ Does the Rest

Follow the onboarding checklist provided in every XLynk™ box. Once powered, XLynk™ chargers will automatically configure themselves and connect.



Always be Informed

Installers can see each charger's connection status to Lynkwell's backend at any time and from anywhere. Simply click on the link received in the email when the project was registered to directly access the information.



Seamlessly Transition to Site Hosts

After all stations have connected to the Lynkwell backend, the site host will receive an email with a link to the Activation Page. Installers no longer need to facilitate the final setup. Site hosts go through a simple and clear onboarding workflow that collects preferences about the site, pricing, banking information, etc.



No Need to Revisit a Site

Installers can move to their next project without costly, time-consuming site revisits. With automated charger configuration and site hosts handling their own activation, projects finish faster—eliminating hours or even days of waiting for charge point operator action.

All USA-Based Team



Lynkwell reserves the right to alter product offerings and specifications at any time without notice. Lynkwell disclaims any and all liability for errors, inaccuracies or incompleteness that may appear in this document. This document does not expand or otherwise modify Lynkwell's terms and conditions or product warranty expressed therein.

lynkwell.com

Follow us   (833) 611-5965



Scan QR Code
for More Info